

PRODUKTBESCHREIBUNG/ SICHERHEITSHINWEISE

1. HAFTUNGSAUSSCHLUSS / GARANTIEBESTIMMUNGEN

DAS GERÄT DARF KEINESFALLS VERÄNDERT WERDEN, IN DIESEM FALLE ERLISCHT JEDER GEWÄHRLEISTUNGSANSPRUCH. MOTOISM ÜBERNIMMT KEINERLEI HAFTUNG FÜR DIREKTE ODER INDIREKTE SCHÄDEN ODER FOLGESCHÄDEN ALLER ART DIE DURCH DIE VERWENDUNG, DEN ANBAU ODER DEN ANSCHLUSS DES INSTRUMENTS, DER SENSOREN ODER DES MITGELIEFERTEN ZUBEHÖRS ENTSTEHEN. DARUNTER FALLEN UNTER ANDEREM ALLE SCHÄDEN AN PERSONEN, SACHSCHÄDEN UND FINANZIELLE SCHÄDEN.

2. MONTAGE

FÜHREN SIE DEN ELEKTRISCHEN ANSCHLUSS SACHGERECHT AUS! WENN SIE NICHT ÜBER DIE NÖTIGE SACHKENNTNIS VERFÜGEN, LASSEN SIE DEN ANSCHLUSS UNBEDINGT VON EINER FACHWERK-STATT DURCHFÜHREN. BITTE BEACHTEN SIE, DASS PRODUKTE, DIE RÜCK- ODER BREMSLICHTER BEINHALTEN, NUR AM FAHRZEUG-HECK VERBAUT WERDEN DÜRFEN.

MAXIMALES ANZUGSMOMENT BEI DER MONTAGE 5 NM.

2.1 MONTAGEHINWEISE

1. Serienheck demontieren. (Sozius entfernen)
2. Kabel des neuen Hecks mit Adapterkabel verbinden. (Kabel stimmen farblich überein)
3. Neues Heck mit den mitgelieferten M8x30 Schrauben montieren. (Schraubensicherung/ Loctite verwenden!)
4. Adapterkabel mit dem originalen Stecker verbinden.

1. DISCLAIMER OF WARRANTY / WARRANTY CONDITIONS

THE INSTRUMENT MUST NOT BE MODIFIED IN ANY WAY, IN THIS CASE ALL WARRANTY CLAIMS WILL BE VOID. IN NO EVENT SHALL MOTOISM BE LIABLE FOR ANY DIRECT, INDIRECT OR CONSEQUENTIAL DAMAGES OF ANY KIND ARISING OUT OF THE USE, INSTALLATION OR CONNECTION OF THE INSTRUMENT, SENSORS OR ACCESSORIES PROVIDED WITH THE INSTRUMENT. THIS INCLUDES, BUT IS NOT LIMITED TO, ALL PERSONAL INJURY, PROPERTY DAMAGE AND FINANCIAL LOSS.

2. INSTALLATION

CARRY OUT THE ELECTRICAL CONNECTION PROPERLY! IF YOU DO NOT HAVE THE NECESSARY EXPERTISE, IT IS ESSENTIAL THAT YOU HAVE THE CONNECTION CARRIED OUT BY A SPECIALIST WORKSHOP. PLEASE NOTE THAT PRODUCTS THAT INCLUDE TAILLIGHTS OR BRAKE LIGHTS MAY ONLY BE INSTALLED ON THE REAR OF THE VEHICLE.

MAXIMUM TIGHTENING TORQUE DURING THE ASSEMBLY 5NM.

2.1 MOUNTING INSTRUCTIONS

1. Disassemble standard rear end. (Remove pillion)
2. Connect cable of new tail with adapter cable. (cables match in color)
3. Mount the new tail with the supplied M8x30 screws. (Use screw lock/ Loctite!)
4. Connect the adapter cable with the original connector.