



Anbauanleitung Fitting Instruction

Artikel-Nr. / Part-No. : **712T046 & 712T046SW**
Produkt : **Ritzelabdeckung**
Product : **Cover, sprocket**
Marke / Brand : **Triumph**
Modell (Typ) / Model (Type) : **Speed Triple (515NJ / 515NV) '08 →**

Wichtige Hinweise:

Lesen Sie die Anleitung sorgfältig durch und beachten Sie alle Sicherheitshinweise. Führen Sie diese Montage nur durch, wenn Sie dafür qualifiziert sind, andernfalls empfehlen wir dringend die Montage in einer Fachwerkstatt. Ein fehlerhafter Anbau kann das Fahrverhalten des Motorrades negativ beeinflussen und Ihre Gesundheit und Ihr Leben gefährden.

Montage:

Das LSL Ritzelabdeckungs-Kit wird Anstelle der originalen Ritzelabdeckung montiert. Mit Buchsen, Schrauben M6x50 und M6x45 die LSL- Ritzelabdeckung montieren. **Die beiden kürzeren Buchsen (l=28mm) auf Position „A“ montieren!** Anzugsdrehmoment 10Nm beachten!

Important:

Read this instruction manual carefully and mind all warnings and tips. You should do this work only if you are qualified; otherwise we recommend this mounting to be done by a qualified workshop. Improperly mounting of this kit can reduce the driveability of the motorcycle and may be a risk to your health and life.

Fitting:

The LSL sprocket cover replaces the original cover. Mount LSL sprocket cover with spacers, bolts M6x50 and bolt M6x45. **Apply both short spacers (l=28mm) on position "A"**. A tightening torque of 10Nm / 7.38lbf ft is recommended.

