

Model schedule for handlebar vibration damper LS 1000 / LS classic from

APRILIA	Model	Code	Year	M6	M8	Comment
	all models until today		all	✓		
	Pegaso 650	MX	96-98	✓		
	SL1000 Falco		99-	✓		Remove original fitting. Mount LS 1000 / LS classic with rubber.
	RSV1000		00-	✓		Remove original fitting. Mount LS 1000 / LS classic with rubber.
	RSV1000R		00-	✓		Remove original fitting. Mount LS 1000 / LS classic with rubber.
	ETV 1000 CapoNord		00-	✓		Remove original fitting. Mount LS 1000 / LS classic with rubber.
BMW	Model	Code	Year	M6	M8	Comment
	all models with M8 thread				✓	
	F650	VB101	95	✓		
	F650/ST		95-00	(✓)		Conditionally.Remove thread at the end of the handlebar (sawing)!
	F650 CS Scarver			(✓)		Conditionally.Remove thread at the end of the handlebar (sawing)!
	F650 GS	172	00-	(✓)		Conditionally.Remove thread at the end of the handlebar (sawing)!
	F650 Dakar	173	00-	(✓)		Conditionally.Remove thread at the end of the handlebar (sawing)!
	K1200LT	K2LT	99-01		✓	
	R45	351	78-80	✓		
	R45	354	80-85	✓		
	R45	355	80-85	✓		
	R65	353	78-80	✓		
	R65	358	80-82	✓		
	R80 G/S	423	80-84	✓		
	K100LT		91	✓		
	R1100S		all		✓	
	R1150, all models		01-		✓	Attention! Don't damage the cable inside the handlebar
Buell	Model	Code	Year	M6	M8	Comment
	all models until today		all	✓		
Cagiva	Model	Code	Year	M6	M8	Comment
	all models until today		all	✓		
	v-Raptor			✓		
	350 W 12	2N1	94-96	✓		
Ducati	Model	Code	Year	M6	M8	Comment
	400 SS	ZDM400J	91-93	✓		
	M 600 Monster	ZDM600M	94-96	✓		
	M 620 ie			✓		
	620 Sport			✓		
	748 SP	748SP	96	✓		
	748 R	ZDM748	00-01	✓		
	749		03-	✓		
	M750 Monster	ZDM750M	96	✓		
	750SS	ZDM750SC	91-97	✓		
	750 SS ie		99-	✓		
	750 Sport			✓		
	M800ie			✓		
	851	ZDM851S3	91	✓		
	851 Strada	ZDM851S1	89-94	✓		
	888 SP	888SP	90-93	✓		
	888 Strada	ZDM888S1	93-95	✓		
	M900 Monster	ZDM900M	93-96	✓		
	M900ie			✓		
	Monster S4		01-02		(✓)	Conditionally. Use about 4 washers
	900SS	ZDM906SC	89-90	✓		
	900SS/SL	ZDM900SC2	91-96	✓		
	900SS		98	✓		
	907ie Paso	ZDM906	91-93	✓		
	ST4	916ST4	99		(✓)	Conditionally.Use about 3-4 washers
	ST4	S200AAYB			✓	
	ST4S				(✓)	Conditionally.Use about 1-2 washers
	916S	ZDM916S	94-98	✓		
	ST2	944ST2	97	✓		
	996	996HS	99	✓		
	998			✓		
	999		03-	✓		
	M1000ie		03-	✓		
	1000SS		03-	✓		
	MultiStrada 1000		03-	✓		
HONDA	Model	Code	Year	M6	M8	Comment
	CB 400N		78-84	✓		
	CM400T	NC01	80-84	✓		
	CX 500	PC03	78-81	✓		
	CX 500C	PC01	79-84	✓		
	CX 500E	PC06	82-84	✓		
	VT500	PC11	83-	✓		
	CB500R	PC32	98	✓		Min. gap between handlebar and vibration damper 1mm. Use washers if necessary.
	CB500	PC26	93-95	✓		Min. gap between handlebar and vibration damper 1mm. Use washers if necessary.
	CB500S	PC32S	98-02	✓		
	CB600F Hornet	PC38	98	✓		
	CBR600F	PC35	99	✓		
	NT650V Deauville	RC33	98	✓		Min. gap between handlebar and vibration damper 1mm. Use washers if necessary.
	CBSevenFifty	RC42	92-02	✓		
	VFR750F	RC24	86-89	✓		Min. gap between handlebar and vibration damper 1mm. Use washers if necessary.
	VFR750F	RC36	94-96		✓	Use about 2 washers M8.
	XRV750 Africa Twin	RD09	90-00	✓		Displace handles and switches up to 5mm if necessary!
	VFR800RC46	VFR	98	✓		Min. gap between handlebar and vibration damper 1mm. Use washers if necessary.
	CBR900RR Fireblade	SC50	02-	✓		Min. gap between handlebar and vibration damper 1mm. Use washers if necessary.
	CBR900RR Fireblade	SC44	00-01	✓		Min. gap between handlebar and vibration damper 1mm. Use washers if necessary.
	CBR900RR Fireblade	SC33	96-99	✓		Min. gap between handlebar and vibration damper 1mm. Use washers if necessary.
	CBR900RR Fireblade	SC28	92-95	✓		Fit with supplied bushing and thick rubber
	Hornet 900	SC48	2	✓		Min. gap between handlebar and vibration damper 1mm. Use washers if necessary.
	VTR1000F	FSC36	97	✓		Min. gap between handlebar and vibration damper 1mm. Use washers if necessary.
	VTR1000SP-1	SC45	0	✓		Min. gap between handlebar and vibration damper 1mm. Use washers if necessary.
	XL1000V Varadero.	SD01	99	✓		Min. gap between handlebar and vibration damper 1mm. Use washers if necessary.
	CB1000F	SC30	93-96	✓		Min. gap between handlebar and vibration damper 1mm. Use washers if necessary.
	CBR1000F	SC24	89-99	✓		Min. gap between handlebar and vibration damper 1mm. Use washers if necessary.
	VTR1000F FireStorm	SC36	97-02	✓		Min. gap between handlebar and vibration damper 1mm. Use washers if necessary.
	CBR1100XX SuperBlackbird	SC35	96-02	✓		Min. gap between handlebar and vibration damper 1mm. Use washers if necessary.
	X-11	SC42	99-02	✓		Min. gap between handlebar and vibration damper 1mm. Use washers if necessary.
	CB1300	SC54	03-	✓		Min. gap between handlebar and vibration damper 1mm. Use washers if necessary.
KAWASAKI	Model	Code	Year	M6	M8	Comment
	EL 250 Eliminator	EL250E	91-95	✓		
	GPZ400R	ZX400D		✓		
	Z440 ltd/G/C	KZ440	80-84	✓		
	ER-5	ER	01-		✓	Use high quality tools because of high tensile screw connections.
	EN 500				✓	Min. gap between handlebar and vibration damper 1mm. Use washers if necessary.
	KLE500		92	(✓)		Conditionally. Drill out 5,2mm. Tap M6. Use 4 washers!
	Z550 ltd/GT/F	KZ550	81-88	✓		
	Zephyr 550			✓		

Model schedule for handlebar vibration damper LS 1000 / LS classic from

	ZX-6R Ninja		95-96		✓	
	ZX-6R 636	ZX600KK	02-04		✓	Use high quality tools because of high tensile screw connections.
	ZX-6R		05-	✓		
	ZZR 600	ZX600	alle		✓	Use high quality tools because of high tensile screw connections.
	W650	EJ650		✓		
	Z750		03-		✓	Use high quality tools because of high tensile screw connections.
	Z750S		04-		✓	Use high quality tools because of high tensile screw connections.
	Zephyr 750	ZR750C	91-95	✓		
	Zephyr 750	ZR750D	96-99	✓		
	ZR-7	ZR750F/Z	99-01		✓	Use high quality tools because of high tensile screw connections.
	ZX7		00-		✓	
	VN800	VN800A	94-96			Appropriate adapter available by appointment
	VN800 Classic	VN800B	96-01			Appropriate adapter available by appointment
	VN800 Drifter	VN800C1	00-01			Appropriate adapter available by appointment
	GPZ900R	ZX900A	84-94		✓	Use high quality tools because of high tensile screw connections.
	ZX-9R	ZX900	02-		✓	Use high quality tools because of high tensile screw connections.
	ZX10R		03-	✓		
	Z1000	ZNT00	03-		✓	Use high quality tools because of high tensile screw connections.
	ZZR1100	ZXT20	03-		✓	Use high quality tools because of high tensile screw connections.
	ZRX1200		03-		✓	Use high quality tools because of high tensile screw connections.
	ZX12-R Ninja	ZXT70	03-		✓	Use high quality tools because of high tensile screw connections.
	all models with M8 thread				✓	Use high quality tools because of high tensile screw connections.
KTM	Model	Code	Year	M6	M8	Comment
	all models with hollow barend		all	✓		
	all models with M8 thread		00-		✓	use washers
	Duke 1			✓		
	Duke 2			✓		
MV Agusta	Model	Code	Year	M6	M8	Comment
	750S		00-03	(✓)		Conditionally. Screw M6*100 and additionally washers necessary.
SUZUKI	Model	Code	Year	M6	M8	Comment
	all models until today		all	✓		
	GZ125 Marauder	AP-GZ	99-00	✓		
	AN125	JS1CF42A		✓		
	GN125	NF41A	91-96	✓		
	GS125 Katana	JS1AW1111	97-	✓		
	GS125 Katana	JS1AW2111	97-	✓		
	VZ125 2c Intruder	JS1A4		✓		
	AN250	JS1AN1111		✓		
	GN250	NJ42A	82-96	✓		
	AN400	JS1AU1111	99-	✓		
	GS500E	GM51A	89-96	✓		
	GS500E Sk2	JS1A9	89-96	✓		
	GSF600F Bandit	JS1A8	95-	✓		
	GSX600F	GN72	96-	✓		
	GSX-R 600	AD111	96-	✓		
	GSX-R 600	JS1BG111	03-	✓		
	RF600	GN76A	96-	✓		
	DR650 alle	JS1SP4	90-91	✓		
	GR650F	GP51A	83-85	✓		
	SV650 S/N	JS1AV	99-	✓		
	GSX750	JS1AE111	98-01	✓		
	GSX750F	AK111		✓		
	GSXR750	GR7DA/B	96-	✓		
	GSXR750	J11BD	02-	✓		
	DR800SDR BIG	JS1SR42A	90-	✓		
	DR800SDR BIG	JS1SR43A	91-96	✓		
	VS800GL Intruder	VS52A		✓		Appropriate adapter available by appointment
	RF900R			✓		
	GSXR1000	JS1BL1	01-	✓		
	SV1000	JS1BX322	03-	✓		
	TL1000S	AG111		✓		
	GSX1100F		94-	✓		
	GSX1200			✓		
	GSF1200 Bandit	GV75A	96-	✓		
	GSXR1300 Hayabusa	A111	99-	✓		
	GSX 1400	JS1BN111		✓		
	VS1400 Intruder	VX51L		(✓)		Appropriate adapter available by appointment
TRIUMPH	Model	Code	Year	M6	M8	Comment
	Speed 4		03-	(✓)		Conditionally. Drill out 5,2mm. Tap M6.
	Sprint ST		03-	(✓)		Conditionally. Use washers.
	Bonneville		00-02	(✓)		Conditionally. Drill out 5,2mm. Tap M6.
	Bonneville America		02-	(✓)		Conditionally. Drill out 5,2mm. Tap M6.
	Speed Triple		03-	✓		
VOXAN	Model	Code	Year	M6	M8	Comment
	all models until today		all	✓		
	Cafe-Racer	vn4v	01-	✓		16mm on the inside
	Roadster		01-	✓		
	Scrambler		01-	✓		
YAMAHA	Model	Code	Year	M6	M8	Comment
	XV125	5AJ	97-	(✓)		Conditionally. Adapter Diameter=21, 15 long; has to be manufactured.
	SR 500, all models	2J4/48T	78-96	✓		
	XT500, all models	1N5/1U6/56U	76-89	✓		
	XJ550	4V8/27A	81-83	✓		
	FZS600 Fazer	RJ021	98-00	✓		
	FZS600 Fazer	RJ021	01-	✓		
	FZS600 Fazer	RJ025		✓		
	FZ-6 S Fazer		04-	✓		
	SRX600	1XM/1XL	85-89	✓		
	XJ600 S/N	4BR	94-	✓		
	XJ600 S/N	4EB/RJ01	98-01	✓		Use 1 or 2 washers M6 if necessary.
	XT600E/K, all models	2KF etc.	84-90	✓		
	XT600	DJ021	02-	✓		
	YZF-R6	RJ03	99-02	✓		
	TDM850	4TX	96-01	✓		
	TDM900	RJ051/RN084		✓		
	XJ900 S	4KM	94-96	✓		
	FZS1000 Fazer	RN06	01-	✓		
	FZR1000		87-88	✓		
	YZF1000R		96	✓		
	YZF1000	4VD/SD	98	✓		
	YZF-R1	RN01	99-	✓		Use 1 or 2 washers M6 if necessary.
	YZF R1	RN095	03-	✓		Use 1 or 2 washers M6 if necessary.
	RT1100 Bulldog Belgarda		02-	(✓)		Bushing necessary. Outside Ø 21mm, inside Ø8, 13mm high; washers M8 if necessary
	XJR1300	RP0	99-02	✓		
	FJR 1300	PR04/PO86		✓		Use 1 or 2 washers M6 if necessary.