

Bonneville/Thruxton Ignition Kit

Advice - If you are not a trained motorcycle mechanic stop now. Ask a local motorcycle shop to do the work for you. Regarding the work you have to do on original Triumph parts please follow the advices of “Triumph Workshop Manual”.

Open the head light to get to the plug/socket connection of ignition lock. Take this part of the harness out of the head light shell. Now demount the ignition unit out of the left head lamp bracket.

The delivered new ignition lock bracket has to be fitted on the right side of the frame with the rhombic window to the top. Therefore take out the original frame bolts and fit the new bracket with the delivered M10x1.25x70 and the distance bushes between frame and bracket. Tighten the bolts with the required torque of 45Nm/33.2 lbf ft.

Now you can refit the ignition unit in the bracket window. To get necessary wire length the connection of plug and socket has to be set out side. The socket unit should be fixed to the right side frame tube (connecting cylinder head) and covered against water penetration.

Before your first ride please check carefully that all screws are fixed tight and all functions work correct.



LSL-Motorradtechnik GmbH • D-47809 Krefeld

www.lsl.eu

Stand: 10.02.2010